Halloween Prop Controller – 2008 and 2009



Switch Positions when in Standby

SW1 – Manual Start

SW2 – Upper Limit (1) – Open when up

SW3 – Rear Tilt (1) – Close when at rear

SW4 – Forward Tilt (1) – Close when at tilt fwd

SW5 – Lower Limit (1) – Open when down

SW6 – Upper Limit (2) – Close when up

SW7 – Rear Tilt (2) – Closes when start forward

SW8 – Forward Tilt (2) – Close when at tilt fwd

SW9 – Lower Limt (2) – Closed when lowered

Tim Whitson
The Fool's Quarter